

## Betriebs-Räumwerkzeuge EVOLVENTEN nach DIN 5482

Nummer	Abmessung	Räumlänge (mm)	Vorbohrm./ Durchmesser	Anz. Züge
LR 0044	A 17 x 14; z = 9; m = 1,6; EW 30°	20 - 50	14 H 8	
LR 0304	A 20 x 17 m=1,6 z=12	18 - 45	17 H7	1
LR 0011	A20 x 17	18 - 40		1
LR 0173	A 22 x 19 z = 13 m = 1,6 EW 30 °	32 - 80		1
LR 0306	A 28 x 25; z = 15; m = 1,75; EW 30°	25 - 62	25 H 8	1
LR 0305	A 28 x 25; z = 15; m = 1,75; EW 30°	25 - 62	25 H 8	1
LR 0322	A 30 x 27; z = 16; m = 1,75; EW 30°	25 - 62	27 H 8	1
LR 0708	A30x27 z=16 m=1,75 EW=30°	20-50	26,77 H8	1
LR 0316	A 35 x 31; z = 18; m = 1,75; EW 30°	25 - 62	31 H 8	1
LR 0317	A 35 x 31; z = 18; m = 1,75; EW 30°	25 - 62	31 H 8	1
LR 0702	A35x31 m=1,75 z=18 EW=30°	16-40	30,75 H7	1
LR 0631	A 38 x 34	36 - 80	34 H 8	1
LR 0320	A 40 x 36	18 - 45	36 H8	1
LR 0629	A 42 x 38, Z = 21, m = 1,9, EW 30°	14 - 35	37,7 H 7	1
LR 0630	A 42 x 38	14 - 35	37,7 H 7	1
LR 0553	A 45 x 41; z = 22; m = 2; EW 30	32 - 80	41 H 8	1
LR 0311	A 45 x 41; z = 22; m = 2; EW 30	32 - 80	41 H 8	1
LR 0323	A 48 x 44 ; Z=23; m= 2; EW=30°	25 - 62	44 H8	1
LR 0568/1 LR 0568/2	A 48 x 44 ; Z=23; m= 2; EW=30°	32 - 80	44 H 8	2
LR 0552	A 50 x 45; z = 24; m = 2; EW 30°	25 - 62	45 H 8	1
LR 0552	A 50 x 45; z = 24; m = 2; EW 30°	25 - 62	45 H 8	1
LR 0430 SWZ	A 58 x 53; m = 2; PL 27; EW 30°	25 - 62	53 H 9	1
LR 0340	A 60 x 55; z = 28; m = 2; EW 30°	32 - 80	55 H 8	2
B 957	A 60 x 55; z = 28; m = 2; EW 30°	32 - 80	55 H8	1
LR0251	A 60 x 55; z = 28; m = 2; EW 30°	32 - 80	55 H8	1
LR 0563/1 LR 0563/2	A 70 x 64; Z=32; m=2,1; EW 30°	28 - 70	64 H 8	2
LR 602/1-2	A 70 x 64; Z=32; m=2,1; EW 30°	28 - 70	64 H 8	2
LR 0598	A 85 x 79; Z=38; m=2,25; EW 30°	15 - 45	79 H 8	1
LR 0597/1 LR 0597/2 LR 0597/3	A 98 X 92; Z=43; m=2,25; EW 30°	50 - 125	92 H8	1